

## 6.0 Replacement Parts List

<b>Part #</b>	<b>Description</b>
<b>041002</b>	<b>Straight Sample Port</b>
<b>041004</b>	<b>Angled Sample Port</b>
<b>041531812</b>	<b>0.5" Dump Valve</b>
<b>041530841</b>	<b>0.75" Dump Valve</b>
<b>041-0133</b>	<b>1.0" Dump Valve</b>
<b>44531815</b>	<b>0.5" Pressure Regulator</b>
<b>44531814</b>	<b>0.75" Pressure Regulator</b>
<b>044-0003</b>	<b>1.0" Pressure Regulator</b>
<b>41-0016</b>	<b>0.2 – 2 GPM Flowmeter</b>
<b>41-0002</b>	<b>0.5 - 5 GPM Flowmeter</b>
<b>41530601</b>	<b>0 - 10 GPM Flowmeter</b>
<b>41-0045</b>	<b>2 - 20 GPM Flowmeter</b>
<b>43530703</b>	<b>0 - 60 PSI Pressure Guage</b>
<b>43530711</b>	<b>0 – 100 PSI Pressure Gauge</b>
<b>55-0003</b>	<b>0.5" Check Valve</b>
<b>55-0004</b>	<b>0.75" Check Valve</b>
<b>55-0017</b>	<b>1.0" Check Valve</b>