

## Spare Parts List

Part #	Description
80-0128	Pump, 3/4HP, Single Phase, 115/230V
80-0129	Pump, 1HP, Three Phase, 208-230/460V
80-0134	Pump, 3/4HP, Three Phase, 208-230/460V
80-0135	Pump, 1HP, Single Phase, 115/230V
041-0033	Check Valve, Ball Spring Loaded
43530710	Stainless Steel Pressure Gauge 0-100psi
61670245	Contactors, AB, 9 AMP, 3 Pole, 120V Coil
61760226	Motor Contactor/Overload 12 AMP Maximum
63760186	Fuse 15A FNW
63760133	Fuse, 2A, 250V
64760225	Timer, 8-Pin, 120V
64760108	Base, Timer, 8-Pin
61-0002	Relay, 30 AMP, 300V, SPST, NO, 120V-Coil