

## Spare Parts List

Part #	Description
80-0138	Pump,3/4HP,Single Phase,115/230V
80-0139	Pump,3/4HP,Three Phase,208-230/460V
80-0140	Pump,1HP,Single Phase,115/230V
80-0141	Pump,1HP,Three Phase,208-230/460V
80-0142	Pump,1.5HP,Single Phase,115/230V
80-0143	Pump,1.5HP,Three Phase,208-230/460V
80-0144	Pump,2HP,Single Phase,115/230V
80-0145	Pump,2HP,Three Phase,208-230/460V
80-0149	Pump,2HP,Three Phase,208-230/460V
80-0158	Pump,2HP,Three Phase,208-230/460V
80-0195	Pump,3HP,Three Phase,208-230/460V
80-0196	Pump,3HP,Single Phase,115/230V
80-0249	Pump,5HP,Three Phase,208-230/460V
43-0021	Gauge,0-100,.25,CBM,2.5,LF,SS/SS
55-0026	VAL,CHECK,1.0 FNPT, 2 PSI SPRING, PP
041732001	Ball Valve,1.25",TU,PVC80
041720169	Ball Valve,1",TU,PVC80
63-0009	Fuse 10A FNM
63760133	Fuse, 2A, 250V
64760225	Timer, 8-Pin, 120V
64760108	Base, Timer, 8-Pin
61-0002	Relay, 30 AMP, 300V, SPST, NO, 120V-Coil